

Rendered Walls

CHECKLIST

- BRITISH PAINTS 4 SEASONS
- BRITISH PAINTS PREP 4IN1
- BROOM OR BRUSH
- HIGH PRESSURE WATER HOSE
- WALL BRUSH – 63MM
- ROLLER – 22MM NAP
- ROLLER POLE
- PAINT TRAY
- MASKING TAPE
- DROP SHEET
- CLEANING SOLUTION
- LADDER
- PAINT STIRRER

Step 1: Render Preparation

- Clean surrounding area, then remove dirt or blistering paint from the wall using a high pressure hose.
- Give the wall a final brush to remove any missed dirt, dust or cobwebs.
- Tape areas you don't want painted and lay drop sheets where required.

Step 2: Paint Preparation

- Stir your paint with a flat stirrer.



If you don't have a paint stirrer, use an old ruler.

Step 3: Application

- Begin by cutting in with a brush. This means painting the edges first and then moving in. Start at the top, then bottom and go around any edges or features.
- Keep a wet edge by not cutting in too early before using the roller.



We recommend painting in weather between 10–30°C.

- Once you've finished cutting in, start painting with the roller.
- Load the roller by dipping it in the paint. Make sure you have an even cover of paint around the roller sleeve before you begin.



If your roller doesn't spin evenly, the paint is uneven and you need to load up again.

Application (cont.)

- Start rolling in an M pattern moving from one side of the wall to the other. Never start in the middle



Use a roller pole to reach further with each stroke.

- Because of the difference in finish between brush and roller, get as close as you can to where you cut in.



Load up your roller more often so you don't have to work as hard.

- Each time you finish a three to four metre section you need to lay off your paint.
- Do this by rolling the roller without loading it up with paint. Then roll from the top of the wall to the bottom in one straight stroke.
- Continue along the length of the painted wall taking care to slightly overlap so you don't cause streaks.
- It's important you maintain a wet edge and complete an entire section of wall before stopping so your finish isn't patchy.
- If the edge dries, it may create a line in your finish.
- Allow at least two hours drying time before applying a second coat.